techguy.nz



YOUR LABEL PRINTER

Your new label printer has a couple of things that you need to do from time to time to keep it working and printing well.

WHEN YOU CHANGE A LABEL ROLL, SOMETIMES YOU WILL NEED TO DO A CALIBRATION.

1. Click start, settings, bluetooth and devices, printers and scanners
2. Find the label printer in the list and click on it, then on the next screen click printer properties.
3. Click on the tools tab
4. Click dropdown menu Action
5. Select RUN CALIBRATION
6. Once thats done, you can close all windows



029 874 5649

paul@techguy.nz